

Color recognition

Color recognition


1. Learning objectives
2. Sensor wiring
3. Code analysis
4. Write and download the program
5. Experimental phenomenon

1. Learning objectives

In this course, we mainly learn how to implement color recognition through python programming.

2. Sensor wiring

The color recognition module is connected to the I2C (SDA, SCL) interface.



3. Code analysis

For the program of this course, please see the **Color-recognition.py** file.

```
from microbit import *  
import WOM_Sensor_Kit
```

First, import the library needed for this lesson from microbit: WOM_Sensor_Kit library is used for sensors.

```


while True:
display.show('R')
sleep(500)
display.scroll(WOM_Sensor_Kit.WOM_color(WOM_Sensor_Kit.WOM_red))
sleep(100)
display.show('G')
sleep(500)
display.scroll(WOM_Sensor_Kit.WOM_color(WOM_Sensor_Kit.WOM_green))
sleep(100)
display.show('B')
sleep(500)
display.scroll(WOM_Sensor_Kit.WOM_color(WOM_Sensor_Kit.WOM_blue))
sleep(100)

```


The letters 'R', 'G', and 'B' are displayed in a loop, and the color sensor values of the red, green, and blue channels are read respectively, and the scrolling is displayed on the screen.

4. Write and download the program


1. Open the Mu software and enter the code in the editing window. **Note! All English and symbols should be entered in English, use the Tab key for indentation, and the last line ends with a blank program.**
2. Click the thumb 'Check' button to check if there are any errors in our code. If a cursor or underline appears in a line, it means a syntax error. Please check and modify it. If there is no error, the lower left corner will prompt that there is no problem with the detection.



3. Click the 'REPL' button to check whether the Superbit library has been downloaded. If not, please refer to [Preparation before class] --> [2.4 Python Programming Guide].



- After the program is written, connect the computer and microbit mainboard with a microUSB data cable, click the 'Flash' button to download the program to the micro:bit mainboard. **(You need to click the 'REPL' button again to turn off the import library file function before you can download the program normally).**



- If the download fails, please confirm whether the microbit is connected to the computer normally via the microUSB data cable and the Superbit Python library has been imported.

5. Experimental phenomenon

After the program runs successfully, the dot matrix displays R, red value, G, green value, B, blue value.

